



TLS701HD/SD/NP-2

Function sketch ---front view



- | | |
|---------------------------|------------------------------------|
| 1 TALLY (indicator) | 7 Adjust downwards / Vvalue switch |
| 2 Power indicator | 8 Adjust upwards / Value switch |
| 3 Power switch | 9 Menu |
| 4 Audio switch / Mute key | 10 Input signal switch |
| 5 Value+ / Volume up | 11 4:3 / 16:9 Aspect ration switch |
| 6 Value- / Volume down | 12 Headphone jack |

Function sketch ---back view



- | | |
|-----------------|-----------------------------|
| 13 Power switch | 17 Composite input / output |
| 14 HDMI input | 18 Audio input |
| 15 TALLY input | 19 HD/SD-SDI input / output |
| 16 Speaker | 20 DC 12V power input |

*TLS701NP-2 no SDI input / output